




Attention: all devices with **selling date 01.03.2017 and newer**, use the standard USB driver (automatic installation). The previous driver from FBE is not compatible with the new devices.
Alternative: download driver from FTDI's homepage and install (<http://www.ftdichip.com/Drivers/VCP.htm>)

Additional settings when USB driver is installed:

<p>After the installation the USB ports are shown as additional COM ports (Device-Manager → Ports (COM & LPT) → USB Serial Port (COMxx))</p>	
<p>Before using CODESYS additional settings for the new COM ports must be done. Open the Properties of the COM ports, go to topic „Port Settings“ and click on „Advanced“.</p>	
<p>Now change the „Latency Timer“ at „BM Options“ to 2 ms. Accept with „OK“ and close the Properties window by clicking „OK“ as well.</p>	

Everything else stays as is, one COM port is for CODESYS, the other one is for the terminal application (HyperTerminal, Tera Term etc.).